

Installation — Power Stands

NOTE

If you purchased your power stand prior to June, 1984 you will need to drill two mounting holes in each leg before installing the casters. Figure 1 shows on which sides of the legs to drill the holes. Make a template to mark the holes. (See Figure 2.) Tape the template in place on the inside of each leg at the bottom. Center-punch hole locations and drill holes with a 9/32" drill bit. Deburr holes.

- 1. Insert the four casters (13) into the plungers (11).
- 2. Place two bolts (15) through the mounting holes in one of the legs. Slip a spacer (16) onto each bolt.
- **3.** Mount one of the caster assemblies onto the bolts. Place the foot pedal on the side of the stand that will be most convenient for you. (NOTE: Both foot pedals should be on the same side of the stand.)
- 4. Add lock washers (17) and nuts (18). Thread nuts but do not tighten yet.
- 5. Repeat steps 2 and 4 to secure other end of caster assembly. Tighten all nuts.
- 6. Repeat steps 2, 3, 4, and 5 to mount the other caster assembly.




Figure 1.



3931 Image Drive Dayton, Ohio 45414





Retractable Casters

Introduction

The retractable casters mount on the Shopsmith Mark V and Shopsmith Power Stands. Follow the appropriate instructions to install the casters.

Tools Required: Large blade screwdriver.

Installation — Mark V

- 1. Insert two casters (13) into the plungers (11) on one of the caster assemblies.
- 2. Line up the holes in the brackets (1, 2) with the holes in the Mark V legs. Position the foot pedal on the speed dial side of the Mark V.
- 3. Start one screw (14) on the right end of the assembly. Add washer (17) and nut (18).
- **4. Install two screws** (14), washers (17) and nuts (18) on the left end of the assembly. Tighten the screws.
- 5. Install remaining screw (14), washer (17) and nut (18) on the right end of the assembly. Tighten both screws.

Parts List

| Ref No. | Part No. | Description | Qty. |
|------------|----------|---------------------------------------|-------|
| 1 | 503809 | Bracket, R.H. | 2 |
| 2 | 503811 | Bracket, L.H. | 2 |
| 3 | 501566 | Cam . | 4 |
| 4 | 503808 | Foot Pedal | 2 |
| 5 | 503807 | Drive Rod | 2 2 2 |
| 6 | 456826 | Rollpin, 5/32" × 1-1/2" | 2 |
| 7 | 513056 | Hex Drive Setscrew, 5/16"-18 | 4 |
| 8 | 503815 | Retaining Clip | 4 |
| 9 | 503817 | Tie Rod | 2 |
| 10 | 273814 | Rollpin, 5/32" × 5/8" | 4 |
| 11 | 503813 | Plunger | 4 |
| 12 | 503814 | Spring | 4 |
| 13 | 503816 | Caster | 4 |
| 14 | 503822 | Screw, 1/4"-20 × 5/8" (Mark V) | 8 |
| 15 | 514133 | Screw, 1/4"-20 × 1-1/4" (Power Stand) | 8 |
| 16 | 514089 | Spacer (Power Stand) | 8 |
| | 115546 | Lock Washer 1/4" | 8 |
| 18 | 120372 | Nut 1/4"-20 | 8 |
| | | | |

